Using the TiVo Button

Purpose

The purpose of this document is to familiarize the user with the TiVo button on the remote control and the available options displayed when it is pressed.

The TiVo Button

The TiVo button can be found on the top portion of the remote control. It has the Tivo logo printed on it.

Directional Keys

Just below the TiVo button are the directional keys that move the cursor around the screen. These will help you navigate around the various screens found within the Guide and Menu.

Pressing the TiVo button will bring up several options. These include

- Messages
- Menu
- Watch TV
- Guide
- My Shows
- What to Watch
- Apps & Games
- On Demand
- Search

Let's look at each selection in detail.

Notifications

Notifications are system generated messages. These messages may contain account specific information, or may simply be system messages about storage space or other things.


Menu

This is where the user configures the settings for the eStream 4K set top box. (STB) There are several parameters that can be set within the menu and these will be discussed in detail in the How-To titled Fioptics+ Menu Settings.


Watch TV

Selecting the Watch TV option will take you to the current channel playing in the background of the menu. You can also press the bottom of the black ring on the remote control to highlight the channels in the "quick guide" below the menu items. Then, pressing on either the left or right of the black ring, you can scroll through the channels and select one to watch. When you have found a channel to watch, simply press the button in the center of the ring to select the program.

Guide

Selecting Guide will bring up the program guide. This is where you can scroll up and down by channel, or left and right by time.

Detailed Guide Information

When you land on a program, detailed information is displayed on the top of the screen.

More Info

While in the Guide and on a program, pressing the *i* button on the remote control will bring up even more detailed information about that program.

My Shows

Selecting My Shows will bring up a list of all of the recordings that have been made by the STB.

Series and One-Time Titles

Select a Series Title to see all of the episodes of the series that the STB has recorded. Selecting an individual title within the series will automatically play the recording.

Selecting a one-time recording will automatically play the recording.

Select *Program* Type

Moving the cursor over to the left of the screen allows you to sort the recordings by the type of program they are. You can select from TV shows, movies, kids, sports and paused programs. The recording list on the right will only display content related to the program type you have selected on the left.

What to Watch

Selecting What to Watch brings up a list of programs by genre.

Genre Types

Some of the genres may include trending movies, feel good movies, tributes to actors, live TV, etc.

This selection is good to go to when you just don't know what you want to watch and need a little help deciding.

Apps & Games

Remember. This STB at its heart is just another Android device, so it does have the ability to run Android apps and games!

Apps & Games List

Here you will find all apps and games that have been downloaded and installed on this STB. To add more apps or games, click on the Google Play Store.


On Demand

This is the place to rent movies!


Browse Categories

Once in On Demand, you can browse titles by category. This is identical to the On Demand library currently found on Cincinnati Bell's Fioptics service.

The library contains thousands of hours of titles in several categories. There is also a ton of free content!

Search

The search function allows you to find the content that you want to watch.

Search Different Ways

Use the Search to find content by title, actor or even director!